

2030 SPEERS ROAD | OAKVILLE, ONTARIO | L6L 2X8 | 1-888-945-5725 | 905-827-0224

13557

06-UP

DODGE

CHARGER CHIN SPOILER

## CONTENTS:

- |                           |                        |
|---------------------------|------------------------|
| 1 - Chin Spoiler          | 8 - 5/16" Lock Washers |
| 8 - 5/16" Hex Bolts       | 8 - 5/16" Hex Nuts     |
| 16 - 5/16" Fender Washers |                        |

## TOOLS REQUIRED FOR INSTALLATION

- |                  |          |
|------------------|----------|
| • 3/8" Drill Bit | • Marker |
| • 1/2" Wrench    | • Drill  |

## INSTALLATION & HARDWARE MOUNTING INSTRUCTIONS

### Please read thoroughly before beginning

1. Fit your new chin spoiler to the front bumper and position in desired location.
2. Using part as a template, mark eight (8) hole locations in the front bumper.
3. Drill eight 3/8" holes in the marked locations.
4. Install bolts, fender washer through the chin spoiler and bumper cover into fender washer lock-washers, nuts.
5. Tighten ALL hardware. **DO NOT OVER-TIGHTEN.**

## NOTE:

This chin spoiler will reduce available ground clearance in front of the vehicle. Use caution when approaching driveways, speed bumps, parking blocks or similar items on the road.

